















---

# SST AND SSM















	Page
SST (SPECIAL SERVICE TOOLS).....	C-2
SSM (SPECIAL SERVICE MATERIALS).....	C-11



### SST (SPECIAL SERVICE TOOLS) (Cont'd)















Section	Part Name	Part No.	Illustration	CL	MT	AT	TF	PR	SA		BR	SR	BE	BO	Note	
									Front	Rear						
		(09310-07010)			●											
		(09310-07020)			●											
		09313-30021								●						Straight screw plug (w/ Differential lock only)
		09315-00021									●					Differential side bearing (2 pinion and LSD types)
		09316-20011			●		●									
		09316-60010			●		●			●	●					
		(09316-00010)			●		●			*1	*2					*1 Drive pinion bearing outer race and oil storage ring *2 Drive pinion bearing outer race
		(09316-00020)			●		●			*1	*2					*1 Drive pinion bearing outer race and oil storage ring *2 Drive pinion bearing outer race
		(09316-00030)					●									
		(09316-00040)					●									
		(09316-00050)					●			*						* Drive pinion bearing outer race
		(09316-00060)					●									
		(09316-00070)					●									
		09330-00021					●			●	●					

### SST (SPECIAL SERVICE TOOLS) (Cont'd)















Section	Part Name	Part No.	Illustration	CL	MT	AT	TF	PR	SA		BR	SR	BE	BO	Note
									Front	Rear					
		<b>09332-25010</b>						●							
		<b>09333-00013</b>		●											
		<b>09336-60010</b>			●										
		<b>09504-00011</b>							●	●					
		<b>09504-22011</b>								●					w/ Differential lock only
		<b>09506-30012</b>							●						
		<b>09506-35010</b>								●					
		<b>09509-25011</b>								●					
		<b>09514-35011</b>								●					
		<b>09517-36010</b>								●					
		<b>09523-36010</b>			●										Output shaft rear ball bearing
		<b>09550-10012</b>								●	●				
		<b>(09252-10010)</b>								●					Differential side bearing (w/ Differential lock only)
		<b>(09552-10010)</b>									●				

















# SST (SPECIAL SERVICE TOOLS) (Cont'd)

Section			CL	MT	AT	TF	PR	SA		BR	SR	BE	BO	Note
Part Name	Part No.	Illustration						Front	Rear					
	(09608-00080) (Replacer)					●								
	(09608-03020) (Handle)			●		●		●						
	(09608-03060) (Replacer)							●						
	(09608-03090) (Replacer)							●						
	09608-30012 Front Hub & Drive Pinion Bearing Tool Set							●		●				
	(09608-00060) (Drive Pinion Front Bearing Cup Replacer)							●						
	(09608-04030) (Front Hub Inner Bearing Cone Replacer)									●				
	(09608-04060) (Front Hub Outer Bearing Cup Replacer)							●						
	09608-35014 Axle Hub & Drive Pinion Bearing Tool Set							●	●					
	(09608-06020) (Handle)							●	●					
	(09608-06110) (Front Hub Inner & Drive Pinion Front Bearing Cup Replacer)								●					
	(09608-06150) (Rear Hub Outer Bearing Cup Replacer)							●	●					
	(09608-06180) (Drive Pinion Rear Bearing Cup Replacer)								●					
	(09608-06200) (Rear Axle Bearing Replacer)							●	●					

## SST (SPECIAL SERVICE TOOLS) (Cont'd)















Section	Part Name	Part No.	Illustration	CL	MT	AT	TF	PR	SA		BR	SR	BE	BO	Note
									Front	Rear					
		(09608-06210)								●	●				
		09609-20011										●			
		09610-55012										●			
		09611-22012							●			●			
		09612-30012		●											
		09612-65014							●			●			
		(09612-01010)							●						Knuckle spindle bushing
		(09612-01030)										●			Manual steering
		(09612-01040)										●			Manual steering
		(09612-01050)							●						Knuckle spindle bushing
		09616-00010										●			
		09616-30020							●	●		●			*1 Differential side bearing adjusting nut (w/ Differential lock only) *2 Manual steering
		09617-60010										●			Manual steering
		09618-60010							●						

## SST (SPECIAL SERVICE TOOLS) (Cont'd)













Section	Part Name	Part No.	Illustration	CL	MT	AT	TF	PR	SA		BR	SR	BE	BO	Note
									Front	Rear					
		09628-62011										●			
		09630-00012		●								●			
		(09631-00020)										●			
		(09631-00050)										●			
		(09631-00060)		●											
		(09631-00070)										●			
		(09631-00090)										●			
		(09631-00120)										●			
		(09631-00140)										●			
		09631-22020										●			
		09632-36010										●			
		09634-60013							●						
		09650-17011								●					
		09703-30010									●				



## SST (SPECIAL SERVICE TOOLS) (Cont'd)

Section	Part Name	Part No.	Illustration	CL	MT	AT	TF	PR	SA		BR	SR	BE	BO	Note
									Front	Rear					
		09709-29017									●				
		09710-22041								●					
		(09710-02020)								●					
		(097104)2050)								●					
		(09710-02070)								●					
		09710-30030								●					
		(09710-03180)								●					
		09717-20010									●				
		09718-00010									●				
		09718-20010									●				
		09726-40010								●	●				• Companion flange
		09727-30020								●					
		09737-00010		●							●				
		09751-36011		●						●	●				

## SST (SPECIAL SERVICE TOOLS) (Cont'd)

Section	Part Name	Part No.	Illustration	CL	MT	AT	TF	PR	SA		BR	SR	BE	BO	Note
									Front	Rear					
		09753-00013		●							●				
		09753-30020		●											
		09753-40010									●				
		09806-30010												●	
		09812-00010												●	
		09910-00015										●			
		(09911-00011)										●			
		(09912-00010)										●			
		09950-00020			●		●		●	●					
		09950-20017			●		●		●	●		●			
		09992-00094				●									
		09992-00241											●		Check for turbo indicator and warning system (1HD-T engine)

NOTE: For reference to SSTs for the Air Conditioning System see page AC-20.

**SSM (SPECIAL SERVICE MATERIALS)**

Part Name	Part No.	Sec.	Use etc.
Seal packing 1281, Three bond 1281 or equivalent	08826-00090	MT	Transmission case x Intermediate plate Transmission case x Front bearing retainer Transfer adaptor x Intermediate plate Transmission case x Shift lever control retainer
		AT	Oil pan x Transmission case
		TF	Front case x Rear case Rear case x Case cover Rear case x Rear extension housing Front case x Front extension housing Front case x Motor actuator
		SA	Differential lock shaft retainer Differential lock actuator Differential lock cover
Adhesive 1324, Three bond 1324 or equivalent	08833-00070	SA	Differential pinion shaft pins and bolts Differential cover lock set bolts Differential lock shift fork set bolt
Adhesive 1344, Three bond 1344, Loctite 242 or equivalent	08833-00080	MT	Front bearing retainer set bolts Oil pump body set bolts Shift lever control retainer set bolts
		TF	Straight screw plug Rear case set bolts (two bolts) Case cover set bolts
		SA	Differential lock shaft retainer set bolt Straight screw plug
		SR	Manual gear housing worm bearing adjusting screw and lock nut Sector shaft end cover
Dupont paste No. 4817	—	BE	Rear window defogger wire
Three cement black	08833-00030	BO	Windshield glass
Adhesive (Super special)	08850-00051	BO	Side protection moulding

NOTE: For reference to SSMs for the Air Conditioning System see page AC-20.